Configuration software ASD Config

V: 2.2.1

Product change request: ----/--

Software identification:

Filename	Software version		Released	Dependency ASD FW
	New	Basis		
ASD Config 2.2.1 Setup Securiton.exe	2.2.1	2.0.0	02.05.2018	see “Compatibility:
ASD Config 2.2.1 Setup Hekatron.exe				
ASD Config 2.2.1 Setup Schrack.exe				

Changes V: 2.2.1:

CR	Type	Description
--	N	New FW for ASD 531/532 V: 01.02.09 in setup (no functional changes)

Obligation to replace:

Only configuration software V: 2.2.1 may be used for all new ASD applications.

Compatibility:

Compatible as of ASD 535 FW V: 01.01.01 (without filter monitoring/operation and ASD NetSoft functionality).

Installation notice

- Minimum system requirements: Windows 7 SP1; 200 MB free hard disk space; 1 GB RAM
  CPU = 2 GHz (single) / 1.5 GHz (dual); GPU = DirectX 9 capable
- Screen resolution: at least 1280 x 720 pixel
- 1 available Ethernet or USB connection and 1 available USB connection for the ULM dongle.
- The ASD Config configuration software can be run with Windows 7 SP1 (32 & 64 bit), Windows 8.1 (64 bit) and Windows 10 (64 bit).
- The corresponding .NET language pack may have to be installed to display the texts correctly in the program.
- Program to display PDF reports (e.g. Adobe Reader). The “Arial Unicode MS” or “Arial Unicode MS Standard” font must be present for Asian symbols to be printed (e.g. installed with MS Office).
- Internet Explorer 11 or Microsoft Edge (Online Help).

If a previous version of ASD Config is installed on the PC, it must be uninstalled prior to the new installation. This is performed via the Control Panel of the PC via “Remove program”.

Notes for the IT administrator:

By entering the following command in the command line, the software can be silently installed or uninstalled:

- Installation: **`"Path\Setup.exe" -q`**
- Deinstallation: **`"Path\Setup.exe" -uninstall -q`**

Remarks:

- The entry between the quotation marks corresponds to the path where the setup file is stored and the file name specified on page 1 (software identification).
- The installation path can be specified with **`InstallFolder="C:\AnyPath"`** (attention: case sensitive). Without this specification the default path is used.

First issue: 02.05.2018 Po/ksa
The product specifications contained in this document are subject to change without notice.
© Copyright by Securiton