


Important !

Static sensitive devices enclosed.

Read this note first



1. Insert the supplied CD into your computer and install the ZP3 USB Programmer software by running (x:)\ZP3 USB Flash Programmer\setup.exe
2. Install ZP Planner on your computer
3. Read the Technote 358, from CD at (x:)\ZP3 Manuals and Documentation\Technote 358 - Planner upgrade procedure.pdf, and follow it's instructions to upgrade ZP3 Panel Software
4. Picture of ZP3-USB Programmer programming ZP3MB2

